

	7*HOM - FSR	HOM Spacing	FSR [Hz]	HOM Splitting (10 - 01)	Alignment: V(01)/V(00)	Mode Matching: V(02)/V(00)
West.300K	4.79 +/- 0.13 MHz	218 +/- 5.7 MHz	1521 +/- 58 MHz	122 +/- 21 kHz	2.8e-3 +/- 7e-4	1.3e-2 +/- 1e-3
East.300K	4.58 +/- 0.17 MHz	212 +/- 3.4 MHz	1480 +/- 56 MHz	96 +/- 14 kHz	1.2e-3 +/- 7e-4	7.7e-2 +/- 5.2e-3
West.125K	4.83 +/- 0.11 MHz	218 +/- 7.4 MHz	1521 +/- 62 MHz		4.4e-3 +/- 1.8e-3	1.3e-2 +/- 6.1e-4
East.125K	4.38 +/- 0.08 MHz	210 +/- 4.0 MHz	1466 +/- 38 MHz		8.7e-3 +/- 2.9e-3	7.8e-2 +/- 6.4e-3