

Understanding Weiner Filter by Optimally Subtracting Seismometer Signal

Sujan Kumar Goungondla

August 5, 2013

The aim of this exercise is to optimally subtract one seismometer signal from another. To do so, a Wiener filter must be computed using one seismometer channel as desired signal and other as observed signal.

Method Adopted

A ten minute signal was taken from 2 seismometer (GUR1 and GUR2) installed at 40m Lab. The start time of the signal was Aug 2 00:00:00 PSD.

For every choice of desired (x) and witness signal(y) a 4000 order Wiener filter (W) was computed using the first 25 seconds of the signal. Witness signal(y) is filtered with the computed Wiener filter (W) to obtain a filtered signal (z). Filtered signal is then subtracted from desired signal (x) to obtain the difference signal (d). We should expect 0 correlation between difference signal and witness signal.

Summary of Results

Desired Signal (x)	GUR1_X	GUR1_Y	GUR1_Z	GUR2_X	GUR2_Y	GUR2_Z
Witness Signal (y)	GUR2_X	GUR2_Y	GUR2_Z	GUR1_X	GUR1_Y	GUR1_Z
Correlation between x and y	-0.0662	-0.2620	0.0565	-0.0662	-0.2620	0.0565
Correlation between d and y	-0.2196	-0.0615	-0.0082	-0.0810	0.0953	-8.21e-4
(Power of D)/(Power of X)	0.3836	0.4547	0.1707	0.2847	0.0941	0.6544

Notes

- The two seismometers were placed far hence the 2 signals were not very correlated.
- Wiener filter is computed with the code written by Keenan Pepper which I obtained from Den.
- Correlation is defined as $\rho_{x,y} = \frac{E[(x-\mu_x)(y-\mu_y)]}{\sigma_x\sigma_y}$.